



JAGUAR CUP



	x 2
	x 2
	x 1
	x 1
A	
	x 3
B	
	x 1
C	
	x 1
D	
	x 1
E	
	x 1
F	
	x 8
	x 4
	x 8
	x 4
	x 18


NOTICE

"TRACK CLEANING"
TO ENSURE THAT YOUR MICRO
SYSTEM PERFORMS AT ITS BEST,
IT MAY BE NECESSARY TO WIPE
EACH RAIL WITH AN ABRASIVE
MATERIAL.


1.E. FINE WET & DRY PAPER,
KITCHEN SCOURER ETC. 3/293

Hornby Hobbies Limited
Westwood, Margate, Kent CT9 4JX


Helpline
Telephone 01843 233525
Fax 01843 233527




1





2




3



4



5



6

Always remove from wall socket when not in use.



Fjernes altid fra stikkontakten, når ikke i brug.

Bei Nichtgebrauch immer den Netzstecker aus der Steckdose ziehen.

Siempre desconecte de la toma de la red eléctrica cuando no esté en uso.

Toujours débrancher de la prise murale après emploi.

Όταν το σετ δεν χρησιμοποιείται πάντα να βγάζετε το βύσμα από την πρίζα.


Togliete sempre la spina dalla presa quando non usate il giocattolo.

Haal het netsnoer altijd uit het stopcontact als de set niet wordt gebruikt.


Quando não estiver a utilizar, retire sempre da tomada de parede.

Kytke laite irti pistorasiasta, kun se ei ole käytössä.

Ta alltid ur transformatorn ur vägguttaget när bilbanan inte används.



7



Always remove the transformer from the socket before cleaning the track.



Fjern altid transformeren fra stikkontakten før banen rengøres.

Vor Reinigen der Fahrbahn den Transformator immer aus der Netzsteckdose ziehen.

Siempre desconecte el transformador de la toma cuando vaya a limpiar la pista.

Le transformateur doit toujours être débranché de la prise avant tout nettoyage de la piste.

Πριν αρχίσετε το καθάρισμα της αιδηροτροχιάς πάντα να βγάλετε τον μετασχηματιστή από την πρίζα.

Togliete sempre il trasformatore dalla presa prima di pulire la pista.


Haal het netsnoer van de transformator uit het stopcontact alvorens de baan te reinigen.

Retire siempre a ficha do transformador da tomada antes de limpar a pista.


Irrota muuntaja pistorasiasta aina ennen radan puhdistamista.

Ta alltid ur transformatorn ur vägguttaget innan du rengör banan.


8



9



10



11

